

# Care & Cleaning Instructions

## M10-E, M10-EST, M20-E, M20-EST TM-15, TM-20, TM-28, TM-500, TM-550

### Cleaning Instructions:

1. Turn off hot and cold water supplies.
2. Remove cover with complete thermostat and bridge assembly, submerge in non-corrosive cleaning solution and flush with clean water.
3. Re-install complete assembly into body of valve, aligning holder nuts into holes in base.

